# Analysis of RDK II Data


Collaboration Meeting March 14, 2012

## Outline

- Signal analysis
- Event selection
- Background subtraction
- Results


# Signal Analysis – Criteria

- The peak
  - rises at least 300 units above the minimum
  - is after the minimum
  - is at least 5.12μs before end of trace
  - is at least 6.4μs (bAPD) or 7.68μs
    (BGO) after beginning of trace
  - is less than 300 units away from the average of neighboring points (same for minimum)
- Minimum chi²/dof of linear regression over signal at least 4900




# Signal Analysis - Baseline

- Linear regression on the range 0≤t≤i for all i
- Calculate Ax+B and chi<sup>2</sup> for each fit
- Save the results for later




# Signal Analysis - Smoothing

- Weighted sum derived from local polynomial regression method
  - Narrow width for timing
  - Wide width for "energy"




# Signal Analysis – Parameters

- Determine  $t_{\gamma}$  and  $E_{\gamma}$ 
  - Floating baseline
  - Max above baseline
  - Rise 10% of peak above baseline




## Signal Analysis – Parameters

- Start at peak
- Use stored fits
- Trace back until chi²/dof<7000</li>
- Trace back until smoothed < 10% of peak



# Signal Analysis - SBD

- Electron time and "energy" from peak channel
- Proton time and "energy" from next highest peak after electron peak reaches a dip
- Subtract average baseline from energies




### **Event Selection**

Only one explicit criteria for ep events


$$t_p - t_e < 26 \mu s$$

- Criteria to look into
  - End of electron signal, t<sub>dip</sub>
  - 50% fall time, t<sub>half</sub>

# Background Subtraction - BGO




## Background Subtraction - bAPD




## Results - BGO

#### Background corrected BGO detectors



## Results - bAPD

#### Background corrected bAPD detectors



### Results

- Ratio epg/ep
  - BGO

$$(1.129\pm0.010)\cdot10^{-4}$$

- bAPD

$$(8.811\pm0.257)\cdot10^{-5}$$